



## USB-MINI-CAB

### Introduction

For installation and operation instructions, please go to [www.axsessinterface.com](http://www.axsessinterface.com) (<http://www.axsessinterface.com/>) and click on the “Firmware Downloads” tab.

### INSTRUCTIONS

1. Download the webxpress updater program from [www.axsessinterface.com](http://www.axsessinterface.com).
2. Once downloaded double click the webxpress program icon located on your desktop and follow prompts. **Note:** *For windows Vista users right click on icon and click “run as administrator”.*
3. Once installed connect the USB-MINI-CAB to your computer (sold separately) and follow prompts to install drivers. **Note:** *Not all computers will need to do this.*
4. Once drivers are installed open the USB bootloader program which is located in the “all program” section of your start menu.
5. Open up the Axxess interface box that needs to be updated to access the micro “B” port on the circuit board.
6. With the USB boot loader program opened, click “update unit board”. When prompted, plug the USB-MINI-CAB into the micro “B” port of the Axxess interface and the board will begin to update to the latest version.





## USB-MINI-CAB

### Introducción

Para ver instrucciones de instalación y operación, visite [www.axsessinterface.com](http://www.axsessinterface.com) (<http://www.axsessinterface.com/>) y haga clic en la pestaña “Firmware Downloads” (Descargas de firmware).

### INSTRUCCIONES

1. Descargue el programa actualizador webxxpress de [www.axsessinterface.com](http://www.axsessinterface.com).
2. Una vez descargado, haga doble clic en el ícono del programa webxxpress localizado en su escritorio y siga las indicaciones. **Nota:** *Si es usuario de Windows Vista, haga clic con el botón derecho en el ícono y haga clic en “ejecutar como administrador”.*
3. Cuando haya instalado el programa, conecte el USB-MINI-CAB a su computadora (se vende por separado) y siga las indicaciones para instalar los controladores. **Nota:** *No es necesario hacer esto en todas las computadoras.*
4. Cuando los controladores se hayan instalado, abra el programa cargador de USB que se localiza en la sección “todos los programas” de su menú de inicio.
5. Abra el cuadro de interfase Axxess que necesita actualizarse para acceder al micro puerto “B” en la tarjeta de circuitos.
6. Con el programa cargador de USB abierto, haga clic en “actualizar la tarjeta de la unidad”. Cuando se le solicite, conecte el USB-MINI-CAB en el micro puerto “B” de la interfase Axxess y la tarjeta empezará a actualizarse a la versión más reciente.

