



HE-DGBK6

20" LED Light Bar Hidden Bumper Mounts

2003-2019 Ram 2500/3500

2003-2009 models, ONLY work with Slimline (HE-SL2014) Light bar
2010-2019 models, work with 20" Dual-Row Light Bars

Installation:

1. Start by removing the two inner factory 18mm bolts that are securing each tow hook to the frame.
2. Place the HEISE bracket around tow hook and replace the previously removed factory bolts. **DO NOT** fully tighten bolts at this point in time.
NOTE: Tow hook does not need to be removed for install. Ensure that the light bar mounting tabs on each of the brackets are facing inward towards each other.
3. Repeat tow hook bolt removal and bracket install for the other side.
4. Once both brackets are in place, install the 20" light bar between the light bar mounting tabs found on the bracket and secure the light bar to the brackets with the supplied bolts.
5. The four 18mm tow hook bolts can be fully tightened after adjustments are made and the desired position is achieved.

1-800-221-0932 www.HeiseLED.com
460 Walker Street, Holly Hill, FL 32117