

## AX-DSP-FD2 T-Harness

Pin 2 - **Brown** - Not in use

Pin 3 - **Pink** - CAN-HI

Pin 4 - **Black/Yellow** - Future use, do not connect

Pin 5 - **White/Black** - Front Left Speaker (-)

Pin 6 - **Grey/Black** - Front Right Speaker (-)

Pin 7 - **Green/Black** - Rear Left Speaker (-)

Pin 8 - **Purple/Black** - Rear Right Speaker (-)

Pins 9 & 19 - Input from the 54-pin harness

Pins 10 & 20 - Not applicable in this application

Pin 11 - **Yellow** - Constant 12-volt Supply

Pin 12 - **Orange** - Control Wire for AX-BASSKNOB

Pin 13 - **Blue/Pink** - CAN-LO

Pin 14 - **Black** - Ground

Pin 15 - **White** - Front Left Speaker (+)

Pin 16 - **Grey** - Front Right Speaker (+)

Pin 17 - **Green** - Rear Left Speaker (+)

Pin 18 - **Purple** - Rear Right Speaker (+)

- If installing **ONLY** a subwoofer, connect the two 8-pin black connectors together. If you are not, leave the 8-pin connectors disconnected.
- If the vehicle is equipped with navigation and/or SYNC 3, connect the **White** and **White/Black** wires on the 54-pin harness, (normally found at the LCD screen) to the **White** and **White/Black** wires on the 20-pin harness. Then connect the 54-pin harness to the wiring harness in the vehicle.

## T-Arnés AX-DSP-FD2

Pin 2 - **Marrón** - No está en uso

Pin 3 - **Rosa** - CAN-HI

Pin 4 - **Negro/Amarillo**- Uso futuro, no conectar

Pin 5 - **Blanco/Negro**- Altavoz delantero izquierdo (-)

Pin 6 - **Gris/Negro** - Altavoz delantero derecho (-)

Pin 7 - **Verde/Negro**- Altavoz trasero izquierdo (-)

Pin 8 - **Púrpura/Negro** - Altavoz trasero derecho (-)

Pins 9 y 19 - Entrada desde el arnés de 54-pins

Pins 10 y 20 - No aplicable en esta aplicación

Pin 11 - **Amarillo** - Suministro constante de 12 volt

Pin 12 - **Orange** - Cable de control para AX-BASSKNOB

Pin 13 - **Azul/Rosa**- CAN-LO

Pin 14 - **Negro** - Cable de tierra

Pin 15 - **Blanco** - Altavoz delantero izquierdo (+)

Pin 16 - **Gris** - Altavoz delantero derecho (+)

Pin 17 - **Verde** - Altavoz trasero izquierdo (+)

Pin 18 - **Púrpura** - Altavoz trasero derecho (+)

- Si instala **SOLAMENTE** un subwoofer, conecte los dos conectores negros de 8-pins juntos. Si no lo está, deje desconectados los conectores de 8-pins.
- Si el vehículo está equipado con la navegación y/o SYNC 3, conecte los cables **blanco** y **blanco/negro** en el arnés de 54 pins (normalmente se encuentra en la pantalla LCD), a los cables **blanco** y **blanco/negro** en el arnés de 20 pins. A continuación, conecte el arnés de 54-pin para el arnés de cableado en el vehículo.