

Ford **A2B** Amp Interface **2017-Up**

Visit [AxxessInterfaces.com](https://www.AxxessInterfaces.com) for more detailed information about the product and up-to-date vehicle specific applications

INTERFACE FEATURES

- Add-on amp interface for Metra dash kits 99-5834CH & 99-5841B
- Retains Bang & Olufsen amp with A2B input for F-150
- Retains Sony amp with A2B input for Fusion
- Retains balance
- Micro-B USB updatable

INTERFACE COMPONENTS

- AXA2B-FD1 harness

APPLICATIONS

FORD

F-150	2018-Up
Fusion	2017-Up

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink • Tape • Wire cutter • Zip ties

Connections & Installation

- Unplug the main harness from port “A” in the touchscreen display, then connect the **AXA2B-FD1 harness** in between.
- Connect the **AXA2B-FD1 harness** to the **AXA2B-FD1 interface**.
- Connect the **Gray** (right) and **White** (left) RCA jacks to the front full range outputs from the aftermarket radio.
- Connect the **Blue/White** wire from the **AXA2B-FD1 harness** to amp turn-on.
- Tape off and disregard the **Blue/Red** wire.

Testing

- Cycle the ignition on and test the installation for functionality.
Note: Fade control will be lost.
- Locate the amp gain between the two connectors. Adjust the gain as needed to balance the level between the woofers and tweeters.
- If the level isn't the same from all speakers, follow the instructions below to correct the issue.
 - Cut the RCA jacks off to expose the speaker wires inside.
 - Connect the following wires to the front speaker outputs from the aftermarket radio:
 - **Gray:** Right + • **White:** Left +
 - **Gray/Black:** Right - • **White/Black:** Left -

