



Backup Camera Retention Harness

Fits Select Models of HYUNDAI/KIA 2015-2020

INTERFACE FEATURES

- Retains the factory backup camera on an aftermarket radio
- Allows for an aftermarket camera to be added to the factory screen

INTERFACE COMPONENTS

- Backup camera retention harness

APPLICATIONS see page 2

For **Dash Disassembly Instructions**, refer to metraonline.com. Enter the year, make, and model of the vehicle in the **Vehicle Fit Guide for Radio Install kits**.

www.MetraOnline.com



TABLE OF CONTENTS

Applications	2
Connections.....	2

TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape
- Wire cutter

Visit AxxessInterfaces.com for more detailed information about the product and up-to-date vehicle specific applications.

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.
NOTE: Refer also to the instructions included with the aftermarket radio.

APPLICATIONS

APPLICATIONS

HYUNDAI

Elantra (with NAV)	2017
Elantra GT (with NAV)	2016-2017
Genesis (Sedan).....	2016
Santa Fe / Sport (with NAV)	2017
Sonata (with NAV).....	2015-2017
Tucson (with NAV).....	2016-2017
Veloster	2016-2017

KIA

Cadenza (with NAV)	2017-2020
Forte / Forte 5 (with NAV)	2017-2018
Niro (with NAV).....	2017-2020
Optima	2017*-2019
Sedona (with NAV).....	2015-2020
Sorento (with NAV).....	2016-2018
Soul/ Soul EV (non-NAV)	2016
Sportage.....	2016

*without 7" Touchscreen

CONNECTIONS

The **AXBUCH-HK1** can be connected two different ways

To retain the factory back-up camera to an aftermarket radio:

- Connect the **Black** wire to chassis ground.
- Connect the **Red** wire to accessory power.*
- Connect the male **Yellow** RCA jack to the rear camera input of the aftermarket radio.

* It is highly recommended to use the AXCS-D-6V (sold separately) to provide the camera with the proper voltage.

To allow an aftermarket camera to be added to the OEM screen:

- Connect the **Black** wire to the aftermarket camera's ground wire.
- Connect the power wire of the aftermarket camera to accessory power.
- Connect the female **Yellow RCA jack** to the aftermarket camera.
- Tape off and disregard the **Red** wire, it will not be used in this application.

Note: Disregard the loose **Green/Purple** wire, it will not be used in this application.



AXBUCH-HK1

INSTALLATION INSTRUCTIONS

Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP
certified technicians**