



## Subaru † Backup Camera Retain/Add-On 2015-Up\*

† Base models with a 6.2-inch screen

\* Visit [axxessinterfaces.com](http://axxessinterfaces.com) for more detailed information about the product and up-to-date vehicle specific applications

---

### INTERFACE COMPONENTS

- AXBUCH-SB2 harness • AXCSD-6V 12V-to-6V step-down

---

### APPLICATIONS

#### SUBARU

Crosstrek	2016-2017	WRX	2016-Up
Forester	2017-2018	WRX (w/ NAV)	2015
Impreza	2015-2016	XV Crosstrek	2015

---

### TOOLS REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape • Wire cutter • Zip ties

## CONNECTIONS

---

**To retain the factory backup camera to an aftermarket radio, connect the:**

- **Black** wire to chassis ground.
- **Black** wire from the **AXCSD-6V** to chassis ground.
- **Red** wire to the **Blue/Red** wire from the **AXCSD-6V**.
- **Blue/White** wire from the **AXCSD-6V** to accessory power.
- **Yellow** *male* RCA jack to the backup camera input from the aftermarket radio.
- Disregard the *female* **Yellow** RCA jack.

**To add an aftermarket backup camera to the factory radio, connect the:**

- **Yellow** *female* RCA jack to the aftermarket backup camera.
- Disregard the *male* **Yellow** RCA jack.
- Disregard the **AXCSD-6V**.
- Tape off and disregard the following (2) wires: **Black, Red**