



Porsche (with M.O.S.T. 25 amplifier) Data Interface 2004-2009

INTERFACE FEATURES

- Provides accessory power
- Retains R.A.P. (retained accessory power)
- Designed for amplified models
- Provides NAV outputs (parking brake, reverse, speed sense)
- Retains balance
- Micro-B USB updatable

INTERFACE COMPONENTS

- AXDI-PO4 interface
- AXDI-PO4 amplifier interface
- AXDI-PO4 harness

APPLICATIONS

PORSCHE

911 (997)	2004-2009	Boxster (987)	2004-2009	Cayman (987c)	2004-2009
-----------	-----------	---------------	-----------	---------------	-----------

TABLE OF CONTENTS

Connections	2
Installation	2

TOOLS REQUIRED

- Wire cutter • Crimp tool • Solder gun • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

Product Info



CONNECTIONS

From the aftermarket radio to the AXDI-P04 harness:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Red** wire to the accessory wire.
- If the aftermarket radio has an illumination wire, connect the **Orange** wire to it.
- Connect the **Blue/White** wire to the amp turn-on wire.

The following (3) wires are only for multimedia/navigation radios that require these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Tape off and disregard the following (8) wires, they will not be used in this application:
Gray, Gray/Black, Green, Green/Black, Purple, Purple/Black, White, White/Black
- Connect the **Red** and **White** RCA jacks to the front amplifier output jacks of the aftermarket radio.

INSTALLATION

With the key in the off position:

- Connect the AXDI-P04 harness to the AXDI-P04 interface.
- Connect the AXDI-P04 harness to the AXDI-P04 amplifier interface.
- Remove the dust cover from fiber optic port in the AXDI-P04 amplifier interface.
- Connect the factory fiber optic cable into the AXDI-P04 amplifier interface.
- Connect the AXDI-P04 harness to the wiring harness in the vehicle.



AXDI-PO4

INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

1-800-253-TECH



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 7:00 PM

Sunday: 10:00 AM - 4:00 PM



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



**Metra recommends MECP
certified technicians**