

**BACKUPCAM**

(For use in GMLAN29 vehicles with OEM installed backup cameras)

**INTRODUCTION**

The BACKUPCAM is designed to retain factory back up cameras to be viewed through the aftermarket radio.

**APPLICATIONS****BUICK**

Enclave	2008-up
Lucerne	2006-2011

**CADILLAC**

DTS	2006-2011
Escalade/ESV/EXT	2007-2011
SRX	2007-2009

**CHEVROLET**

Avalanche	2007-2011
Avalanche <i>without NAV</i>	2012-up
Cheyenne <i>without NAV</i>	2012-up
Equinox	2007-2009
Express	2008-2012
Express <i>without NAV</i>	2013-up
Impala	2006-2013
Monte Carlo	2006-2007
Silverado	2007-2011
Silverado <i>without NAV</i>	2012-2013
Suburban	2007-2011
Suburban <i>without NAV</i>	2012-up
Tahoe	2007-2011

Tahoe <i>without NAV</i>	2012-up
Traverse	2009-up

**GMC**

Acadia	2007-up
Savana	2008-2012
Savana <i>without NAV</i>	2013-up
Sierra	2007-2011
Sierra <i>without NAV</i>	2012-2013
Yukon	2007-2011
Yukon <i>without NAV</i>	2012-up

**HUMMER**

H2	2008-2009
----	-----------

**PONTIAC**

Torrent	2007-2009
---------	-----------

**SATURN**

Outlook	2007-2010
Vue	2008-2010

**SUZUKI**

XL-7	2007-2009
------	-----------

**INTERFACE INSTALLATION**

From the 16-pin harness:

- Connect the Yellow RCA to the back up camera input of the aftermarket radio.

**1-800-221-0932****metraonline.com**

**BACKUPCAM**

(Para el uso en vehículos con GMLAN29 OEM cámaras de seguridad instaladas)

**INTRODUCCIÓN**

El BACKUPCAM está diseñado para mantener una copia de seguridad de fábrica cámaras para ser visto a través de la radio no original.

**APLICACIONES****BUICK**

Enclave	2008 y mas
Lucerne	2006-2011

**CADILLAC**

DTS	2006-2011
Escalade/ESV/EXT	2007-2011
SRX	2007-2009

**CHEVROLET**

Avalanche	2007-2011
Avalanche <i>sin NAV</i>	2012 y mas
Chevyenne <i>sin NAV</i>	2012 y mas
Equinox	2007-2009
Express	2008-2012
Express <i>sin NAV</i>	2013 y mas
Impala	2006-2013
Monte Carlo	2006-2007
Silverado	2007-2011
Silverado <i>sin NAV</i>	2012-2013
Suburban	2007-2011
Suburban <i>sin NAV</i>	2012 y mas
Tahoe	2007-2011

Tahoe <i>sin NAV</i>	2012 y mas
Traverse	2009 y mas

**GMC**

Acadia	2007 y mas
Savana	2008-2012
Savana <i>sin NAV</i>	2013 y mas
Sierra	2007-2011
Sierra <i>sin NAV</i>	2012-2013
Yukon	2007-2011
Yukon <i>sin NAV</i>	2012 y mas

**HUMMER**

H2	2008-2009
----	-----------

**PONTIAC**

Torrent	2007-2009
---------	-----------

**SATURN**

Outlook	2007-2010
Vue	2008-2010

**SUZUKI**

XL-7	2007-2009
------	-----------

**INSTRUCCIONES DE INSTALACIÓN**

Desde el arnés de 16 pins:

- Conecte el RCA amarillo a la parte trasera de entrada de cámara de la radio del mercado de accesorios.

**1-800-221-0932****metraonline.com**