

AXM-DC-BT

Universal Bluetooth streaming FM modulator

KIT FEATURES

- 4 FM frequencies to choose from
- Optional 3.5mm/RCA audio input
- 2.1 amp USB charging under dash port
- RDS capable (must have AVRCP 3.1 or higher)
- Bluetooth range of approximately 30 meters

COMPONENTS

- AXM-DC-BT interface
- Circular on/off rocker switch
- AXM-DC-BT harness
- Under dash mount USB charging port

CONNECTIONS TO BE MADE

- Connect the **Red** wire to 12-volt accessory.
- Connect the **Black** wire to chassis ground.
- Connect the male antenna lead into the factory radio.
- Connect the female antenna lead into the antenna plug from the vehicle.
- The **GRAY** and **White** wires will be discussed later in the manual.

Note: Antenna adaptors may be required to connect the AXM-DC-BT to the vehicle. Visit metraonline.com for specific antenna adapter application, or check with the place of purchase.

ROCKER SWITCH

- Drill a 19/32" (15mm) hole in the desired location for the rocker switch.
- Place the rocker switch in the drilled hole.
- Connect the 2-pin plug from the rocker switch to the 2-pin plug of the AXM-DC-BT harness.

PAIRING THE AXM-DC-BT

1. Turn on the vehicle.
2. With your Bluetooth enabled cell phone go into your Bluetooth settings and search for a device.
3. After the search Access BT will show up on your phone.
4. Select it and your phone will pair with the AXM-DC-BT.
5. Pairing is complete and you are now able to stream audio.

(continued on next page)



SELECTING YOUR FM FREQUENCY

There are four FM frequencies to choose from. Grounding the **White** and **Gray** wires in different combinations will set the FM frequency. Below is a flow chart on how to select your FM frequency.

Gray	White	Frequency
Ground	Ground	87.9 MHz
Ground	No connection	88.3 MHz
No connection	Ground	106.3 MHz
No connection	No connection	107.9 MHz

USING THE AXM-DC-BT

1. Make sure your Bluetooth device is paired to the AXM-DC-BT.
2. Select the desired FM frequency on your radio.
3. Select audio to play from your Bluetooth device.
4. At this point audio will start playing through your factory radio.

AUX MODE

Simply plug in the audio source to the provided 3.5mm jack or RCAs and audio will play over the selected FM frequency.

Note:

1. When AUX mode is in use Bluetooth mode is disabled.
2. RDS is not available in AUX mode.



KNOWLEDGE IS POWER
 working in the most recognized and respected
 industry in the world. We are the experts.
 Log on to www.metraonline.com or call
 1-800-221-0932 for information and like steps
 toward a better tomorrow.



Metra recommends MECP
 certified technicians

Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio.