

## CHRYSAV

### Introduction

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

**Note:**

- The CHRYSAV is designed to work with the overhead video monitors that **do not** have the DVD player built in.
- This harness **must** be used along with an Axxess interface. Please visit [axsessinterfaces.com](http://axsessinterfaces.com) for more information.

### APPLICATIONS

**CHRYSLER**

Town & Country	2008-up
----------------	---------

**DODGE**

Durango	2008-2013
Grand Caravan	2008-up
Journey	2009-2010
Ram 1500	2009-2011
Ram 2500/3500	2010-2011

**JEEP**

Grand Cherokee	2008-2013
----------------	-----------

**RAM**

1500/2500/3500	2012
----------------	------

**VOLKSWAGEN**

Routan	2009-2013
--------	-----------

## INTERFACE COMPONENTS

- CHRYSAV harness

## TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

## INSTALLATION INSTRUCTIONS

*Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.*

### From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.

## Instrucciones de instalación para CHRYSAV

## CHRYSAV

### Introducción

El CHRYSAV está diseñado para proporcionar una entrada de audio/video a la pantalla de video OEM para techo del radio de mercado secundario y proporcionar entrada de audio/video del panel de control del asiento trasero al radio de mercado secundario.

**Nota:**

- El CHRYSAV está diseñado para funcionar con los monitores de video de techo que **no** tienen el reproductor de DVD integrado.
- El arnés **se tiene que** usar con la interfaz de Axxess. Por favor visite [axsessinterfaces.com](http://axsessinterfaces.com) para más información.

### APLICACIONES

**CHRYSLER**

Town & Country	2008-up
----------------	---------

**DODGE**

Durango	2008-2013
Grand Caravan	2008-up
Journey	2009-2010
Ram 1500	2009-2011
Ram 2500/3500	2010-2011

**JEEP**

Grand Cherokee	2008-2013
----------------	-----------

**RAM**

1500/2500/3500	2012
----------------	------

**VOLKSWAGEN**

Routan	2009-2013
--------	-----------

## Instrucciones de instalación para CHRYSAV

## COMPONENTES DE LA INTERFASE

- CHRYSAV arnés

## HERRAMIENTAS REQUERIDAS

- Cortador • Pelacables • Cinta • Conectores (p. ej., conectores a tope, tapas acampanadas, etc.)

## INSTRUCCIONES DE INSTALACIÓN

*Importante: Antes de empezar el siguiente procedimiento, desconecte la terminal negativa de la batería para evitar un corto circuito accidental.*

### Desde el arnés de 22-pins

- Conecte los conectores RCA "A/V 1" a la entrada de audio/video del radio de mercado secundario. Conecte el conector **amarillo** de entrada a la entrada de video, el **rojo** a la entrada de audio derecha y el **blanco** a la entrada de audio izquierda.
- Conecte los conectores RCA "A/V 2" a la salida de audio/video del radio de mercado secundario. Conecte el conector **amarillo** a la salida de video, el **rojo** a la salida de audio derecha y el **blanco** a la salida de audio izquierda.
- Conecte el conector RCA **amarillo** a la entrada de la cámara de reversa del radio de mercado secundario.
- Conecte el cable **negro** suelto a tierra.