

TE-BSDK Update

Symptoms experienced that will require the update, the TE-BSDK will produce an audible sound and flash regardless of which trigger was used. This means that if you have the left trigger activated, and the sensor on the right detects an object, the audible tone will alert, even though you're only expecting feedback if there is something detected by the left sensor.

This is how to update your TE-BSDK to correct this issue.



The unit that will require the update.











Download the update file from the TE-BSDK item page on the iBeam website.


https://ibeamusa.com/product/te-bsdk








Download and Unzip the update files.



Prepare a Micro-SD card and copy the .bin file to the SD card.





Insert this SD card into the control box then power the unit on.

 The right indicator light will glow and ring for about 2 seconds and then stop, means upgrade was successfully.

Step 1 Step 2 Step 3





