adaptiv



Adaptiv Touchpad User Guide

About

The Adaptiv Touchpad is designed specifically to work with Adaptiv interfaces. Each Touchpad is designed to fit perfectly into the original cupholder housing in the vehicle it was designed for.

Kit Includes

1 x Vehicle specific wireless touchpad
1 x USB receiver

Connecting your Touchpad

Each Touchpad is already paired to the USB receiver supplied.

1. Connect the USB receiver to the Adaptiv interface. This can be plugged into either the 'USB' or 'Multimedia' socket shown in the diagram below (**A**,**B or C**). If both sockets are occupied, a USB hub can be used in the 'USB' socket (**B**).



2. Should you need to pair the Touchpad with the receiver, this can be done as instructed below:

A: Twist the cover off the Touchpad.

B: Ensure the power switch is turned on.

C: Press the Pair button, as shown. The LED will illuminate.

D: Connect the receiver to the Adaptiv interface. Wait for the LED on on the Touchpad to go off. The Touchpad and receiver are now paired.

Batteries

The batteries supplied with the Touchpad are rechargeable.
Should you need to replace the batteries, they should only be replaced with batteries of the same specification:

Li-ion 14500 3.6V 750mAh

Technical Support

Connects2 want to provide a fast and suitable resolution should you encounter any technical issues. With this in mind, when contacting Connects2, try to provide as much Information as possible. This will speed up the process and help us to help you.

Please use our dedicated online technical support centre: support.connects2.com