



Audi Data Interface with SWC 2002-2015

INTERFACE FEATURES

- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (retained accessory power)
- Provides NAV outputs (parking brake, reverse, speed sense)
- Retains audio controls on the steering wheel
- Designed for both Bose, and non-Bose models
- Retains balance and fade
- Micro “B” USB updatable

INTERFACE COMPONENTS

- AX-AU12-SWC interface
- LD-BX-AU1 harness
- LD-BX-AU2 harness
- 16-pin harness with stripped leads
- Female 3.5mm connector with stripped leads

APPLICATIONS

AUDI

Applications below use LD-BX-AU1:	Applications below use LD-BX-AU2:
A3* 2006-2013	A3† 2006-2007
A4/RS 4/S4 w/ NAV 2005-2008	A4/S4‡ 2006
A4/RS 4/S4 2007-2008	A4/S4 2002-2005
A4/RS 4/S4* 2006	A6/RS 6/S6 2002-2004
A4/S4 Convertible 2009	allroad 2004-2005
TT/TTS 2008-2015	TT 2002-2006

* Only for models with either a Symphony Plus or a NAV radio.

† Non-navigation Concert or Symphony radio only

‡ Non-navigation Symphony radio only

TABLE OF CONTENTS

Connections to be made	2-6
- For LD-BX-AU1 applications equipped with a Bose amp	2
- For LD-BX-AU1 applications equipped without a Bose amp	3
- For LD-BX-AU2 applications equipped with a Bose amp	4
- For LD-BX-AU2 applications equipped without a Bose amp	5
- 3.5mm jack steering wheel control retention	6
Installing the AX-AU12-SWC	6
Initializing the AX-AU12-SWC	6
Troubleshooting the AX-AU12-SWC	6
Steering wheel control settings	7-9
L.E.D. feedback	7
Changing radio type	7
Remapping the steering wheel control buttons	8
Dual assignment instructions (long button press)	9
Resetting the AX-AU12-SWC	10

TOOLS REQUIRED

- Wire cutter • Crimp tool • Solder gun • Tape
- Connectors (example: butt-connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

CONNECTIONS TO BE MADE (LD-BX-AUI APPLICATIONS)

Attention! This interface will work with models that are equipped with or without a Bose amplifier. Please follow the instructions carefully for your model vehicle. Failure to do so will result in improper sound. If you are unsure if your vehicle is equipped with a Bose amplifier or not, please contact your local dealership.

For models equipped *with* a Bose sound system:

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the **Red** wire to the accessory wire.
- Connect the **Orange** wire to the illumination wire. If the aftermarket radio does not have an illumination wire, tape off and disregard the **Orange** wire.
- Connect the **Blue/White** wire to the amp turn on wire. This wire must be connected to hear sound from the factory amplifier.

Note: *There is a Blue wire on the LD-BX-AUI harness to connect as well.*

The following (2) wires are for multimedia/navigation radios that require these wires. If not required, tape them off and disregard them.

- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Tape off and disregard the following (9) wires, they will not be used in this application: **Blue/Pink, Green, Green/Black, Purple, Purple/Black, White, White/Black, Gray and Gray/Black.**

From the LD-BX-AUI harness to the aftermarket radio:

- Connect both the **Black** and **Black/White** wires to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Blue** wire to the amp turn on wire. This wire must be connected to hear sound from the factory amplifier.

The following (1) wire is for a multimedia/navigation radio that requires this wire. If not required, tape it off and disregard it.

- Connect the **Blue/Pink** wire to the speed sense wire (V.S.S.), if applicable.
- Connect the **White** RCA jack to the left front RCA output.
- Connect the **Gray** RCA jack to the right front RCA output.
- Connect the **Green** RCA jack to the left rear RCA output.
- Connect the **Purple** RCA jack to the right rear RCA output.

Note: *It is highly recommended that the radio being used has (2) sets of RCA outputs to retain balance and fade; (3) sets if a subwoofer amplifier will be added.*

- Tape off and disregard the following (8) wires, they will not be used in this application: **Green, Green/Black, Purple, Purple/Black, White, White/Black, Gray, and Gray/Black.**

Continue to 3.5mm jack steering wheel control retention

CONNECTIONS TO BE MADE (LD-BX-AU1 APPLICATIONS)

Attention! This interface will work with models that are equipped with or without a Bose amplifier. Please follow the instructions carefully for your model vehicle. Failure to do so will result in improper sound. If you are unsure if your vehicle is equipped with a Bose amplifier or not, please contact your local dealership.

For models equipped *without* a Bose sound system:

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the (2) **Red** wires to the accessory wire.
- Connect the **Orange** wire to the illumination wire. If the aftermarket radio does not have an illumination wire, tape off and disregard the **Orange** wire.
- Connect the **Blue/White** wire to the amp turn on wire. This wire must be connected to hear sound from the factory amplifier.

Note: There is a **Blue** wire on the LD-BX-AU1 harness to connect as well.

The following (2) wires are for multimedia/navigation radios that require these wires. If not required, tape them off and disregard them.

- Connect the **Green/Purple** wire to the reverse wire, if applicable.
- Connect the **Light Green** wire to the parking brake wire, if applicable.
- Tape off and disregard the following (9) wires, they will not be used in this application: **Blue/Pink, Green, Green/Black, Purple, Purple/Black, White, White/Black, Gray and Gray/Black.**

From the LD-BX-AU1 harness to the aftermarket radio:

- Connect both the **Black** and **Black/White** wires to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Blue** wire to the amp turn on wire. This wire must be connected to hear sound from the factory amplifier.

The following (1) wire is for a multimedia/navigation radio that requires this wire. If not required, tape it off and disregard it.

- Connect the **Blue/Pink** wire to the speed sense wire (V.S.S.), if applicable.
- Connect the **Green** RCA jack to the left rear RCA output.
- Connect the **Purple** RCA jack to the right rear RCA output.
- Disregard the **White** RCA jack, it will not be used in this application.
- Disregard the **Gray** RCA jack, it will not be used in this application.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Tape off and disregard the following (4) wires, they will not be used in this application: **Green, Green/Black, Purple and Purple/Black.**

Continue to 3.5mm jack steering wheel control retention

CONNECTIONS TO BE MADE (LD-BX-AU2 APPLICATIONS)

Attention! This interface will work with models that are either Bose amplified, or non-Bose amplified. Please follow the instructions carefully for your model vehicle. Failure to do so will result in improper sound. If you are unsure if your vehicle is Bose amplified or not, please contact your local dealership.

For models equipped *with* a Bose sound system:

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the **Red** wire to the accessory wire.
- If the aftermarket radio has an illumination wire, connect the **Orange/White** wire to it.
- Connect the **Blue/White** wire to the amp turn on wire.

Note: There is a **Blue/White** wire on the BX-AU2 harness to connect as well.

The following (3) wires are for multimedia/navigation radios that require these wires. If not required, tape them off and disregard them.

- Connect the **Blue/Pink** wire to the VSS/speed-sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Tape off and disregard the following (8) wires, they will not be used in this application: **Green, Green/Black, Purple, Purple/Black, White, White/Black, Gray, and Gray/Black.**

From the LD-BX-AU2 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Blue/White** wire to the amp turn on wire.
- Connect the **White** RCA jack to the left front RCA output.
- Connect the **Gray** RCA jack to the right front RCA output.
- Connect the **Green** RCA jack to the left rear RCA output.
- Connect the **Purple** RCA jack to the right rear RCA output.

Note: It is highly recommended that the radio being used has (2) sets of RCA outputs to retain balance and fade; (3) sets if a subwoofer amplifier will be added.

- Tape off and disregard the following (8) wires, they will not be used in this application: **Purple, Purple/Black, Green, Green/Black, Gray, Gray/Black, White and White/Black**

Continue to 3.5mm jack steering wheel control retention

CONNECTIONS TO BE MADE (LD-BX-AU2 APPLICATIONS)

Attention! This interface will work with models that are either Bose amplified, or non-Bose amplified. Please follow the instructions carefully for your model vehicle. Failure to do so will result in improper sound. If you are unsure if your vehicle is Bose amplified or not, please contact your local dealership.

For models equipped *without* a Bose sound system:

From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the **Red** wire to the accessory wire.
- If the aftermarket radio has an illumination wire, connect the **Orange/White** wire to it.
- Connect the **Blue/White** wire to the amp turn on wire.
- Connect the **Purple** RCA jack to the right rear RCA output.
- Connect the **Green** RCA jack to the left rear RCA output.
- Disregard the **Gray** RCA jack, it will not be used in this application.
- Disregard the **White** RCA jack, it will not be used in this application.

The following (3) wires are for multimedia/navigation radios that require these wires. If not required, tape them off and disregard them.

- Connect the **Blue/Pink** wire to the VSS/speed-sense wire.
- Connect the **Green/Purple** wire to the reverse wire.
- Connect the **Light Green** wire to the parking brake wire.
- Tape off and disregard the following (9) wires, they will not be used in this application: **Purple, Purple/Black, Green, Green/Black, Gray, Gray/Black, White and White/Black.**

From the LD-BX-AU2 harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Yellow** wire to the battery wire.
- Connect the **Blue/White** wire to the amp turn on wire.
- Connect the **Gray** wire to the right front positive speaker output.
- Connect the **Gray/Black** wire to the right front negative speaker output.
- Connect the **White** wire to the left front positive speaker output.
- Connect the **White/Black** wire to the left front negative speaker output.
- Tape off and disregard the following (4) wires, they will not be used in this application: **Purple, Purple/Black, Green and Green/Black.**

Continue to 3.5mm jack steering wheel control retention

CONNECTIONS TO BE MADE (CONT)

3.5mm jack steering wheel control retention:

- The 3.5mm jack is to be used to retain audio controls on the steering wheel.
- For the radios listed below, connect the included *female 3.5mm connector with stripped leads*, to the male 3.5mm SWC jack from the LD-BX-AU1 or LD-BX-AU2 harness. Any remaining wires tape off and disregard.
 - **Eclipse:** Connect the steering wheel control wire, normally **Brown**, to the **Brown/White** wire of the connector. Then connect the remaining steering wheel control wire, normally **Brown/White**, to the **Brown** wire of the connector.
 - **Metra OE:** Connect the steering wheel control Key 1 wire (**Gray**) to the **Brown** wire.
 - **Kenwood or select JVC with a steering wheel control wire:** Connect the **Blue/Yellow** wire to the **Brown** wire.
Note: *If your Kenwood radio auto detects as a JVC, manually set the radio type to Kenwood. See the instructions under changing radio type.*
 - **XITE:** Connect the steering wheel control SWC-2 wire from the radio to the **Brown** wire.
 - **Parrot Asteroid Smart or Tablet:** Connect the 3.5mm jack into the AX-SWC-PARROT (sold separately), and then connect the 4-pin connector from the AX-SWC-PARROT into the radio.
Note: *The radio must be updated to rev. 2.1.4 or higher software.*
 - **Universal “2 or 3 wire” radio:** Connect the steering wheel control wire, referred to as Key-A or SWC-1, to the **Brown** wire of the connector. Then connect the remaining steering wheel control wire, referred to as Key-B or SWC-2, to the **Brown/White** wire of the connector. If the radio comes with a third wire for ground, disregard this wire.
Note: *After the interface has been programmed to the vehicle, refer to the manual provided with the radio for assigning the SWC buttons. Contact the radio manufacturer for more information.*
- **For all other radios:** Connect the 3.5mm jack from the LD-BX-AU1 or LD-BX-AU2 harness, into the jack on the aftermarket radio designated for an external steering wheel control interface. Please refer to the aftermarket radios manual if in doubt as to where the 3.5mm jack goes to.

INSTALLING THE AX-AU12-SWC

With the key in the off position:

- Connect the 16-pin harness with stripped leads, and either the LD-BX-AU1 or LD-BX-AU2 harness, into the interface.
- Connect either the LD-BX-AU1 or LD-BX-AU2 harness, to the wiring harness into the vehicle.
Note: *If retaining steering wheel controls, ensure the jack/wire is connected before proceeding onto the next step.*

INITIALIZING THE AX-AU12-SWC

- For the steps below, the **Red** L.E.D. (located inside the interface, next to the potentiometer) can only be seen while active. The interface does not need to be opened to see the L.E.D.
- Turn the key (or push-to-start button) to the ignition position, the L.E.D. will turn on.
- Within a minute, the L.E.D. will turn off for a couple seconds, then flash slowly (up to (18) times, indicating which radio is connected to the interface), and then turn off. Pay close attention as to how many slow flashes there are. This will help in troubleshooting, if need be. Refer to the L.E.D. feedback section for more information.
- Within a few seconds the L.E.D. will turn on, and the radio will turn off.
- Within a minute the L.E.D. will turn off, and the radio will come back on, indicating the initialization process is successful.
Note: *If the radio does not come back on within a minute, the interface is not communicating to the vehicle. Turn the key off, check all connections, and then try again. The interface may need to be reset at this point.*

TROUBLESHOOTING

- If the vehicle has engine noise after installing the AX-AU12-SWC, use Axxess part number AX-AGL610, qty. (2) for Bose, qty. (1) for non-Bose.

STEERING WHEEL CONTROL SETTINGS

L.E.D. feedback

The (18) Red L.E.D. flashes represent what brand radio the AX-AU12-SWC believes it is connected to. Each flash represents a different radio manufacturer. For example, if you are installing a JVC radio, the AX-AU12-SWC will flash (5) times. Following is a legend that dictates which manufacturer corresponds to which flash.

L.E.D. feedback legend

1 flash - Eclipse (Type 1) †	10 flashes - Clarion (Type 2) †
2 flashes - Kenwood †	11 flashes - Metra OE
3 flashes - Clarion (Type 1) †	12 flashes - Eclipse (Type 2) †
4 flashes - Sony / Dual	13 flashes - LG
5 flashes - JVC	14 flashes - Parrot **
6 flashes - Pioneer / Jensen	15 flashes - XITE
7 flashes - Alpine *	16 flashes - Philips
8 flashes - Visteon	17 flashes - TBD
9 flashes - Valor	18 flashes - JBL

* **Note:** If the AX-AU12-SWC flashes Red (7) times, and you do not have an Alpine radio connected to it, that means the AX-AU12-SWC does not detect a radio connected to it. Verify that the 3.5mm jack is connected to the correct steering wheel jack/wire in the radio.

** **Note:** Part number AX-SWC-PARROT is required (sold separately). Also, the Parrot radio must be updated to rev. 2.1.4 or higher through www.parrot.com.

† **Note:** If you have a Clarion radio and the steering wheel controls do not work, change the radio type to the other Clarion radio type; same for Eclipse. The following section explains how to do this.

‡ **Note:** If you have a Kenwood radio and the L.E.D. feedback comes back as showing as a JVC radio, change the radio type to a Kenwood. The following section explains how to do this.

Attention: The Axxess Updater App can also be used to program the following (3) sub-sections as well, pending that the interface has been initialized and programmed.

Changing radio type

If the LED flashes do not match the radio you have connected, you must manually program the AX-AU12-SWC to tell it what radio it is connected to.

1. After (3) seconds of turning the key on, press and hold the Volume-Down button on the steering wheel until the L.E.D. in the AX-AU12-SWC goes solid.
2. Release the Volume-Down button; the L.E.D. will go out indicating we are now in Changing Radio Type mode.
3. Refer to the Radio Legend (next page) to know which radio number you would like to have programmed.
4. Press and hold the Volume-Up button until the L.E.D. goes solid, and then release. Repeat this step for the desired radio number you have selected.
5. Once the desired radio number has been selected, press and hold the Volume-Down button on the steering wheel until the L.E.D. goes solid. The L.E.D. will remain on for about (3) seconds while it stores the new radio information.
6. Once the L.E.D. goes off, the Changing Radio Type mode will then end. You can now test the steering control wheel controls.

Note: If at any time the user fails to press any button for a period longer than (10) seconds, this process will abort.

Continued on the next page

STEERING WHEEL CONTROL SETTINGS (CONT)

Radio legend

- | | | |
|---------------------|----------------------|-------------|
| 1. Eclipse (Type 1) | 7. Alpine | 13. LG |
| 2. Kenwood | 8. Visteon | 14. Parrot |
| 3. Clarion (Type 1) | 9. Valor | 15. XITE |
| 4. Sony/Dual | 10. Clarion (Type 2) | 16. Philips |
| 5. JVC | 11. Metra OE | 17. TBD |
| 6. Pioneer/Jensen | 12. Eclipse (Type 2) | 18. JBL |

Remapping the steering wheel control buttons

Let's say you have AX-AU12-SWC initialized and you want to change the button assignment for the steering wheel controls. For example, you would like "Seek-Up" to be "Mute". Follow the steps below to remap the steering wheel control buttons:

1. Ensure the AX-AU12-SWC is visible so you can see the L.E.D. flashes to confirm button recognition.

Tip: *Turning the radio off is recommended.*

2. Within the first 20 seconds of turning the ignition on, press and hold the "Volume-Up" button on the steering wheel until the L.E.D. goes solid.
3. Release "Volume-Up", the L.E.D. will then go out; "Volume-Up" has now been programmed.
4. Follow the list in the Button Assignment Legend, to reference the order in which the steering wheel control buttons need to be programmed.

Note: *If the next function on the list is not on the steering wheel, press the Volume-Up button for (1) second until the L.E.D. comes on, and then release the Volume-Up button. This will tell the AX-AU12-SWC that this function is not available and it will move on to the next function.*

5. To complete the remapping process, press and hold the Volume-Up button on the steering wheel until the L.E.D. in the AX-AU12-SWC goes out.

Button assignment legend

- | | |
|-------------------|------------------------|
| 1. Volume-Up | 10. Band |
| 2. Volume-Down | 11. Play/Enter |
| 3. Seek-Up/Next | 12. PTT (Push to Talk) |
| 4. Seek-Down/Prev | 13. On-Hook |
| 5. Source/Mode | 14. Off-Hook |
| 6. Mute | 15. Fan-Up * |
| 7. Preset-Up | 16. Fan-Down * |
| 8. Preset-Down | 17. Temp-Up * |
| 9. Power | 18. Temp-Down * |

** Not applicable in this application*

Note: *Not all radios will have all of these commands. Please refer to the manual provided with the radio, or contact the radio manufacturer for specific commands recognized by that particular radio.*

Continued on the next page

STEERING WHEEL CONTROL SETTINGS (CONT)

Dual assignment instructions (long button press)

The AX-AU12-SWC has the capability to assign (2) functions to a single button, except Volume-Up and Volume-Down. Follow the steps below to program the button(s) to your liking.

Note: *Seek-Up and Seek-Down come pre-programmed as Preset-Up and Preset-Down for a long button press.*

1. Turn on the ignition but do not start the vehicle.
2. Press and hold down the steering wheel control button that you want to assign a long press function to for about (10) seconds, or until the L.E.D. flashes rapidly. At this point release the button; the L.E.D. will then go solid.
3. Press and release the Volume-Up button the number of times corresponding to the new button number selected. Refer to the Dual Assignment Legend. The L.E.D. will flash rapidly while the Volume-Up button is being pressed, and then go back to a solid L.E.D. once released. Go to the next step once the Volume-Up button has been pressed the desired number of times.

Caution: *If more than (10) seconds elapses between pressing the Volume-Up button, this procedure will abort, and the L.E.D. will go out.*

4. To store the long press button in memory, press the button that you assigned a long press button to (the button held down in Step 2). The L.E.D. will now go off indicating the new information has been stored.

Note: *These steps must be repeated for each button you would like to assign a dual purpose feature to. To reset a button back to its default state, repeat Step 1, and then press the Volume-Down button. The L.E.D. will go out, and the long press mapping for that button will be erased.*

Dual assignment legend

- | | | |
|-------------------|----------------|-----------------|
| 1. Not allowed | 7. Preset-Up | 13. On-Hook |
| 2. Not allowed | 8. Preset-Down | 14. Off-Hook |
| 3. Seek-Up/Next | 9. Power | 15. Fan-Up * |
| 4. Seek-Down/Prev | 10. Band | 16. Fan-Down * |
| 5. Mode/Source | 11. Play/Enter | 17. Temp-Up * |
| 6. ATT/Mute | 12. PTT | 18. Temp-Down * |

* *Not applicable in this application*

Continued on the next page

Resetting the AX-AU12-SWC

1. With the radio on, turn the potentiometer:

Note: Before proceeding, remember the position the potentiometer is at.

Turn left the LED will come on hold until the LED goes out

Turn right the LED will come on hold until the LED goes out

Turn back left the LED will come on hold until the LED goes out

Turn right the LED will come on hold until the LED goes out

Turn back left the LED will begin to flash rapidly

Turn back to the initial position

The rapid flash means the interface is starting its re-programming process.

2. The L.E.D. inside the interface will turn off for a couple seconds, then flash fast, then flash slowly (up to (18) times, indicating which radio is connected to the interface), and then turn off. Pay close attention as to how many slow flashes there are. This will help in troubleshooting, if need be. Refer to the L.E.D. feedback section for more information.
3. Within a few seconds the L.E.D. will turn on, and the radio will turn off.
4. Within a minute the L.E.D. will turn off, and the radio will come back on, indicating the resetting and initialization process was successful.



AX-AU12-SWC

INSTALLATION INSTRUCTIONS



IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at 1-800-253-TECH. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians