



TE-CM43 User Manual

iBeamUSA.com
MetraDealer.com
techsupport@metra-autosound.com



TECH SUPPORT
800-253-8324

1. Mirror



3. Specification

Screen size	4.3 inch
Display screen	Frameless TFT LCD panel
Display resolution	480(H)x234(V)
Display mode	16:9 / 4:3
Power consumption	4W
Working voltage	DC10-15V
Video input	AV1
Signal system	PAL / AUTO / NTSC

4. Operation

- (1) Pull down on lower spring loaded clips, and place mirror monitor over factory reverse mirror.
- (2) Run cables, avoid areas that may pinch the cable.
- (3) Connect yellow RCA to reverse camera output,
- (4) Connect red wire to switched +12V.
- (5) Connect black wire to ground (a metal, non-painted surface).
- (6) The screen only works when it has video signal going into it. When mirror receives video signal, the screen turns on. When the signal is removed, the screen turns off.

5. General Instruction

This rear view mirror monitor is designed for car rear view purpose, which can work with a reversing camera (NTSC or PAL) to show the real-time image behind your car. When the reverse gear is engaged, the rear view system automatically starts to work, and when the monitor is powered off, the mirror functions just like a normal rear view mirror as the monitor is hidden and almost invisible.

IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line at 1-800-253-TECH. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry.

Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians

Attention

When connecting with power cable, please make sure not to mistake the positive and negative pole, otherwise the fuse will blow immediately for security protection. If it happens, please replace the blown fuse with a new one with same specification, after connecting properly to the right pole. Don't randomly increase the current rating of the fuse, and NEVER use metal wire as a substitute.