



### Toyota Tacoma 2005-2011

Visit [MetraOnline.com](http://MetraOnline.com) for more detailed information about the product and up-to-date vehicle specific applications


#### KIT FEATURES

- DDIN provision
- DIN radio provision with pocket sold separately
- Painted scratch resistant matte black


#### KIT COMPONENTS

- A) Radio housing • B) Radio brackets • C) Hazard switch bracket • D) Panel clips (5) • E) #4 x 3/8" Phillips screws (5) • F) #8 x 3/8" Phillips screws (4)


A



B



C



D



E



F



#### TABLE OF CONTENTS

|                        |   |
|------------------------|---|
| Dash Disassembly ..... | 2 |
| Kit Preparation.....   | 2 |
| Kit Assembly.....      | 3 |

#### WIRING & ANTENNA CONNECTIONS

Wiring Harness: Visit [metraonline.com](http://metraonline.com) and [axessinterfaces.com](http://axessinterfaces.com) for audio/video and steering wheel control interface options.  
Antenna Adapter: Not required

#### TOOLS REQUIRED


- Panel removal tool • Phillips screwdriver
- Socket wrench

**Attention!** With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections are secure before cycling the ignition to test this product.


## DASH DISASSEMBLY

1. Unclip, unplug and remove the climate control panel. (Figure A)
2. Remove the (4) 10mm screws securing the bottom of the radio/clock/hazard assembly. (Figure B)
3. Unclip, unplug, and remove the radio/clock/hazard assembly. (Figure C)


*Continue to Kit Preparation*



(Figure A)



(Figure B)




(Figure C)

## KIT PREPARATION

**From the factory radio/clock/hazard assembly:**

1. Unclip and remove the clock/hazard switch assembly. (Figure A)

*Continue to Kit Assembly*



(Figure A)


## KIT ASSEMBLY

1. Attach the **hazard switch bracket** to the **radio housing** using the (5) #4 x 3/8" Phillips screws supplied. (Figure A)


WARNING: DO NOT OVERTIGHTEN THE SCREWS.

2. Clip the factory hazard switch assembly into the hazard switch bracket/radio housing assembly. (Figure B)


3. Attach the **radio brackets** to the **radio housing** using the (4) #8 x 3/8" Phillips screws supplied (Figure C)



(Figure A)



(Figure B)




(Figure C)

4. Attach the radio to the **radio brackets** using screws supplied with the radio. (Figure D)


5. Attach the (5) **panel clips** to the radio housing assembly. (Figure E)

6. Locate the factory wiring harness and antenna connector in the dash, and complete all necessary connections to the radio. Metra recommends using the proper mating adapter from Metra and/or AXCESS. Re-connect the negative battery terminal and test the radio for proper operation.

7. Snap the radio housing assembly into the dash and reassemble the dash in reverse order of disassembly.



(Figure D)



(Figure E)



**95-8275B**  
INSTALLATION INSTRUCTIONS



Having difficulties? We're here to help.



Contact our Tech Support line at:

**386-257-1187**



Or via email at:

[techsupport@metra-autosound.com](mailto:techsupport@metra-autosound.com)

**Tech Support Hours (Eastern Standard Time)**

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP  
certified technicians**