

COMPONENTS

- Amplifier integration interface
- Extension harnesses

- Vehicle-specific T-harness
- Bass knob

APPLICATIONS

Visit AxxessInterfaces.com for current application list

Amplifier Integration Interface

Fits Select GM Models 2021-Up

Visit AxxessInterfaces.com for more detailed information about the product and up-to-date vehicle specific applications.

FEATURES

- Designed for non-amplified systems
- Provides 6 channels of 5-volt RMS audio
- Non-fading full-range output (channels 5 and 6)
- Simple plug-n-play installation behind the radio
- · Chime level adjustment
- No programming required
- Dual-colored LED feedback light
- Input: 50W per channel
- Amp turn on trigger (DC): 250mA
- 2-channel S/PDIF out (front)

For **Dash Disassembly Instructions**, refer to metraonline.com. Enter the year, make, and model of the vehicle in the **Vehicle Fit Guide** for **Radio** Install kits.

www.MetraOnline.com



TABLE OF CONTENTS

nstallation: Adding a Full-Range Amp and
Subwoofer to a Factory System2-3
roubleshooting: Final LED Feedback4

TOOLS & INSTALLATION ACCESSORIES REQUIRED

- Crimping tool and connectors, or solder gun, solder, and heat shrink
- Tape
- Wire cutter
- Zip ties
 Multimeter

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.

NOTE: Refer also to the instructions included with the aftermarket accessory before installing this device.

INSTALLATION: ADDING A FULL-RANGE AMP & SUBWOOFER TO A FACTORY SYSTEM

Adding a full-range amp and subwoofer to a factory system:

This feature offers the ability to add a fullrange amp and sub to a factory system. (Refer to **Page 3**)

Note: The interface provides a 12-volt 1-amp output to turn on aftermarket amp(s). If installing multiple amps, an SPDT automotive relay will be required if the amp turn-on current of all amps combined exceeds 1-amp. Use Metra part number E-123 (sold separately) for best results.

Installation

- Disassemble the dash, unplug all connectors, and remove the factory radio.*
- 2. Install the **AXAMP-GM32 vehicle T-harness** to the vehicle radio harness and make all the necessary connections. Leave the 2-pin amp turn on wire disconnected.
- **3.** Plug the 20-pin harness from the **AXAMP- GM32 T-harness** into the interface.
- 4. Connect the Amp Turn-on wire.

*NOTE: If the vehicle is amplified, connect the 8-pin harness "A" to 8-pin harness "C". If the factory system is not amplified **DO NOT** connect the 2-pin harness. (See system graphics on page 3)

- 5. Connect the 2-pin **Amp Turn On Wire** to the interface and then connect to the aftermarket amplifiers.
- Connect RCAs to the FRONT, REAR or SUB output of the AXAMP-GM32 interface, then connect to the corresponding amplifier.
- **7.** Adjust your aftermarket amplifier to a desired listening level.

RPAD Installation

NOTE: You will need to install the included RPAD2 to the 8-pin harness "C" located on the vehicle T-harness plugged into the factory radio.

Bass Knob Adjustment:

The bass knob connects to the 2 wires from the 20-pin connector labeled **BASS KNOB**.

The bass knob is used to adjust the output of Channels 5 & 6 of the AXAMP.

Adjustment is as follows:


Counterclockwise turn lowers the volume of channels 5 & 6.

Clockwise turn raises the volume of channels 5 & 6.

Extension Harness

- Connect the included Extension Harness 8-pin harness "B" to the 8-pin harness "A" on the vehicle T-harness to connect factor speaker locations.
- Connect the end of the Extension Harness to the aftermarket amplifier.

CONNECTIONS





TROUBLESHOOTING

Final LED Feedback

At the end of programming the LED will turn **Solid Green** which indicates programming was successful. If the LED didn't turn **Solid Green**, reference the list below to understand which programming section the problem may stem from.

Feedback Light	Condition/Status
Solid Green	All Good
Solid Red	Missing CAN Frames
Blink Red	Clipping Output
Green/Red	Missing Adv. (Comm Frames)

Having difficulties? We're here to help.



Contact our Tech Support line at: **386-257-1187**



Or via email at: techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM Saturday: 10:00 AM - 5:00 PM Sunday: 10:00 AM - 4:00 PM



Metra recommends MECP certified technicians