Data Interface
Fits Select Ford Models **2011-2023**

FEATURES
- Designed for standard amplified systems
- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (Retained Accessory Power)
- Provides NAV outputs (parking brake, reverse, speed sense)
- Pre-wired for Axxess SWC interface (sold separately)
- Retains balance & fade
- Micro "B" USB updatable

COMPONENTS
- AXDI-FD2 Interface
- AXDI-FD2 Harness

APPLICATIONS

Ford

EcoSport	2018-2019 Harman	Ranger	2019-2023
Escape	2013-2019 4.3" screen	Transit	2015-2019 AM/FM/CD
Fiesta	2011-2019 4.3" screen	Transit Connect	2014-2016

Product Info

TOOLS & INSTALLATION ACCESSORIES REQUIRED
- Crimping tool and connectors, or solder gun, solder, and heat shrink • Tape • Wire cutter
- Zip ties • Multimeter tester

Visit **AxxessInterfaces.com** for more detailed information about the product and up-to-date vehicle specific applications.

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product.
NOTE: Refer also to the instructions included with the aftermarket accessory before installing this device.

From the AXDI-FD2 harness to the aftermarket radio

Steering Wheel Control Interface
(Sold Separately)

12-Pin

SWC Harness

Vehicle Connector

Interface

Fuse Holder

Radio Connections

LD-AX-XSVI-FD2

12-Pin

Aftermarket Radio
(Your radio's features may vary)

Front

Rear

AUX-IN

Rear View

Sub

SWC

Black - Ground wire
Yellow - Battery wire
Green - Rear left speaker + output
Green/Black - Rear left - speaker output
Green/Purple - Reverse backup camera
Light Green - Parking brake
Orange - Illumination
Blue - Amp turn on
Blue/Pink - VSS/Speed-Sense
Gray - Front right + speaker
Gray/Black - Front right - speaker
White - Front left + speaker
White/Black - Front left - speaker
Purple - Rear right + speaker output
Purple/Black - Rear right - output
Red - Accessory Power

INSTALLATION

With the key in the off position:

1. Connect the **AXDI-FD2 harness** into the **AXDI-FD2 interface**, and then to the wiring harness in the vehicle.

   Note: If installing an Axxess SWC interface, connect it after you program and test the AXDI-FD2, with the key in the off position.

PROGRAMMING

Attention! If the interface loses power for any reason, the following steps will need to be performed again.

1. Cycle the engine on.

   Note: If the radio doesn't come on within 60 seconds, turn the key to the off position, disconnect the interface, check all connections, reconnect the interface, and then try again.

2. Cycle the ignition off, then back on.

3. Test all functions of the installation for proper operation.

Having difficulties? We're here to help.

📞 Contact our Tech Support line at:
386-257-1187

✉ Or via email at:
techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM
Saturday: 10:00 AM - 5:00 PM
Sunday: 10:00 AM - 4:00 PM

Metra recommends MECP certified technicians