



AXGM-16

INSTALLATION INSTRUCTIONS



INTERFACE COMPONENTS

- AXGM-16 interface
- LD-GMOS-26 harness
- LD-GMOS-210 harness
- LD-2NAVAMP harness

APPLICATIONS

Cadillac

Catera	1997-2001	Eldorado	1999-2002
CTS	2003-2007	Seville	1996-2004
Deville	1996-2005	SRX (with RPO codes UZR U2S).....	2004-2006

Data Interface

Fits Select Cadillac Models 1996-2007

INTERFACE FEATURES

- Designed for amplified systems
- Provides accessory power (12-volt 10-amp)
- Retains R.A.P. (Retained Accessory Power)
- Provides NAV outputs (parking brake, reverse, mute, and speed sense)
- Prewired for Axxess SWC interface (sold separately)
- Retains chimes
- Retains OnStar®/OE Bluetooth® connectivity
- Adjustable gain control for chimes and OnStar®
- Retains balance & fade
- USB updatable

TABLE OF CONTENTS

Connections	
LD-GMOS-26 harness	2
LD-GMOS-210 harness	3
Installation	4
Programming.....	4


TOOLS & INSTALLATION ACCESSORIES REQUIRED

- Cutting tool • Tape • Crimping tool
- Connectors (i.e. butt-connectors, bell caps, etc.)


Visit AxxessInterfaces.com
for more detailed information about the product
and up-to-date vehicle specific applications

ATTENTION: With the key out of the ignition, disconnect the negative battery terminal before installing this product. Ensure that all installation connections, especially the air bag indicator lights, are plugged in before reconnecting the battery or cycling the ignition to test this product. **NOTE:** Refer also to the instructions included with the aftermarket accessory before installing this device.

CONNECTIONS: LD-GMOS-26 & LD-2NAVAMP



CONNECTIONS: LD-GMOS-210 & LD-2NAVAMP





AXGM-16

INSTALLATION INSTRUCTIONS

INSTALLATION

With the key in the off position:

- Connect either the **LD-GMOS-26 harness** or **LD-GMOS-210 harness** and **LD-2NAVAMP harness** into the interface, and then to the wiring harness in the vehicle.

PROGRAMMING

Attention! If the interface loses power for any reason, the following steps will need to be performed again. If installing an Axxess SWC interface, connect it after you initialize and test the interface/radio, with the key in the off position.

- Turn the key (or push-to-start button) to the ignition position and wait until the radio comes on.

Note: If the radio does not come on within 60 seconds, turn the key to the off position, disconnect the interface, check all connections, reconnect the interface, and then try again.

- Turn the key to the off position, and then to the accessory position. Test all functions of the installation for proper operation, before reassembling the dash.

Having difficulties? We're here to help.



Contact our Tech Support line at:

386-257-1187



Or via email at:

techsupport@metra-autosound.com

Tech Support Hours (Eastern Standard Time)

Monday - Friday: 9:00 AM - 7:00 PM

Saturday: 10:00 AM - 5:00 PM

Sunday: 10:00 AM - 4:00 PM



**Metra recommends MECP
certified technicians**